
PSC 103 - Spring 2018 - Arduino Weather Station Lab

**Light: Wiring with SD-Card** 



(For code, see next page.)

## **Light: Code**

```
#include <SD.h>
void setup()
  Serial.begin(9600);
  pinMode(10, OUTPUT);
 SD.begin(10);
 SD.remove("data.csv");
}
void loop()
  float L;
  unsigned long t;
  File out;
  L = analogRead(A0) * 5.0 / 1024;
  Serial.println(L);
  delay(1000);
  t = millis();
  out = SD.open("data.csv", FILE_WRITE);
  out.print(t);
out.print(",");
  out.println(L);
  out.close();
}
```