
PSC 103 - Spring 2018 - Arduino Weather Station Lab

Temperature: Wiring with SD-Card



Temperature - Code

```
#include <SD.h>

void setup()
{
    Serial.begin(9600);
    pinMode(10, OUTPUT);
    SD.begin(10);
    SD.remove("data.csv");
}

void loop()
{
    float x, T;
    File out;
    unsigned long t;

    x = analogRead(A0) * 5000.0 / 1024;
    T = (x - 500.0) / 10.0;
```

```
T = T * 1.8 + 32.0;
Serial.println(T);
delay(1000);

t = millis();
out = SD.open("data.csv", FILE_WRITE);
out.print(t);
out.print(",");
out.println(T);
out.close();
}
```